

Instructions: Deluxe Seat Back Gun Case

⚠ WARNING:

TAKE CARE WHEN TRANSPORTING ANY FIREARM.

- NEVER transport a loaded firearm
- NEVER transport firearms within the reach of children


Materials list:

- 1 Deluxe Seat Back Gun Case with Detachable Scabbard
- 1 metal support rod (two-piece)
- 2 elastic hooked cords

Installation


1. Lay your Seat Back Gun Case down on a flat surface with the zippered side down.
2. Connect the two-piece support rod [A] by pushing the two pieces together.

3. Insert the support rod into the webbing tube on the black, back side of your Gun Case at the top. Secure by closing the rip-and-grip tab.



4. If your seat has a removable headrest lift the headrest a couple inches.

Hold your gun case against your seat back with the pockets facing out and the webbing straps [B] at the top. Loop the webbing straps around the headrest posts or seat top and clip the side-release buckles together.



5. Reposition any headrests. Adjust the length of the webbing straps around the headrests as needed.


6. CAREFULLY attach the hooked elastic cords [C] to the D-rings on the bottom of each pocket section to the underside of your seat. Take care—if the hook does not catch the cord can release and cause injury.

7. Insert your rifles or shotguns into the zippered pockets. Do not put more than one gun into one pocket.

Attaching The Gun Scabbard

To attach your scabbard, find the rip-and-grip straps on the back side of the scabbard. Insert the straps through the plastic loops on the Gun Case.

Match up the rip-and-grip panels on both the case and scabbard for extra holding support.



Cleaning

Machine wash in COLD water.

DO NOT USE SOAP as it may remove the protective coatings added by the factory. Line dry or machine dry on air or delicate.

Two Year Warranty

This product is factory warranted for workmanship and materials for two years after purchase. This warranty does not cover firearms carried in the gun case.



Classic Accessories, Inc.
Kent, WA, USA 98032
www.classicaccessories.com
©2007