

# Instructions: Deluxe Kennel Jacket

## Installation

Your Deluxe Kennel Jacket fits kennels with or without wheels.

1. Stand your empty kennel on end with the door side down. If possible, remove the wheels.
2. Unzip the front door of your Deluxe Kennel Jacket, put the door opening over the back end of your kennel and slip the jacket down over your kennel. Be sure that the wheel openings on your Kennel Jacket have cleared the wheels. Replace the wheels if you removed them.
3. You can adjust the length of the four top side straps to size the Kennel Jacket to your kennel.

## Doors and windows

The door and both windows can be held open by rolling them up and closing the two straps at the top around the rolled up fabric.




## Food bag and pockets

The handy food bag at the rear can be detached for filling or carrying using the two clips at the top. To dispense kibble just open the chute on the bottom side.

To insure a water-tight seal fold the top as shown.

There are pockets on the door and top for a leash and other supplies. Please note that the mesh and top pockets are NOT water proof.



## Safety

ALWAYS leave at least a slight opening in both windows or the door so that your dog has adequate air and ventilation.

Detachable  
food  
bag



NEVER leave your dog unattended in your kennel. Even on overcast days the temperature can build up surprisingly fast inside the kennel.

Your Kennel Jacket is highly water resistant but no fabric is completely water proof. Check your dog in sustained wet conditions.

Please be sure that your dog has adequate water and food while inside the kennel.

The handle on your jacket is not designed to bear the weight of moving a kennel with a dog inside the kennel.

## Care

Hand wash or machine wash on gentle cycle in COLD water. DO NOT USE SOAP as it can damage the protective coatings on the fabric. Line dry or machine dry on air or delicate.

Do not store your Kennel Jacket in an enclosed area when it is wet—it could mildew.

## One Year Warranty

This product is factory warranted for workmanship and materials for one year after purchase.



Classic Accessories, Inc.  
Kent, WA, USA 98032  
[www.classicaccessories.com](http://www.classicaccessories.com)  
©2007

# **WARNING**

- **ALWAYS** leave at least an opening in both windows or the door of your Kennel Jacket so your dog has adequate air and ventilation. **IF YOU LEAVE YOUR DOG IN YOUR KENNEL WITH THE JACKET WINDOWS AND DOOR COMPLETELY CLOSED YOUR DOG COULD SUFFOCATE.**
- **NEVER** leave your dog unattended in your kennel. Even on overcast days the temperature can build up surprisingly fast inside the kennel with the jacket on.
- **NEVER** put more than one dog in your kennel when your Kennel Jacket is on.



Classic Accessories, Inc.  
Kent, WA, USA 98032  
[www.classicaccessories.com](http://www.classicaccessories.com)

©2007

07cP59\_004